




**F.M. AUTO
E SERVIZI**


Cambi automatici

Subaru 5EAT OEM spare parts



© F.M. Auto & Servizi
Drivetrain specialists
www.fmautoeservizi.com
info@fmautoeservizi.it









**F.M. AUTO
E SERVIZI**

Cambi automatici

Subaru 5EAT OEM spare parts



31705AA4309L

© F.M. Auto & Servizi
Drivetrain specialists
www.fmautoeservizi.com
info@fmautoeservizi.it






Torque converters

OEM codes: 31100AB120 - 31100AB121

Further torque converters OEM codes available



Oil pump assembly

Composed by OEM codes: 31327AA070 - 31341AA110 - 15008AA130



Phonic wheel

OEM code: 30818AA000



Planetary gear set

OEM code: 31055AA000



Input shaft


OEM code: 30815AA011



Mid planet ring gear
OEM code: 30820AA001




Mid planet carrier
OEM code: 30819AA000



Rear planet carrier with ring gear
OEM code: 31056AA000



Shaft with sun gear and flywheel
OEM code: 30824AA000



Valve body
OEM code: 31705AA430